01W - Wattsville - Sawyer

Airport details

State	Virginia
Country	United States of America
Region	
Elevation	13ft (4m)
Timezone	GMT -5
Coordinates	37.99282, -75.59286
Type	land
ICAO code	01W
IATA code	n/a
FAA code	n/a

Runway info

Runway 17S / 35-S-	
length	8752607m (28715902ft)
bearing	117° / 297°
width	18m (60ft)
surface	grass
Runway 10 / 28	
length	281m (922ft)
bearing	90° / 270°
width	18m (60ft)
surface	grass

Communication

No airport communication available for 01W

Nearby beacons

code	identifier	dist	bearing	frequency
SWL	SNOW HILL VORTAC	7.2	63.6°	112.40
SBY	SALISBURY VORTAC	21.5	13.1°	111.20
OX	LANDY (OCEAN CITY) NDB	29	46.8°	407
PXT	PATUXENT (PATUXENT RIVER) VORTAC	42	290°	117.60
NHK	PATUXENT NDB	42.1	289.8°	400
NHK	NAS PATUXENT RIVER TACAN	42.3	289.4°	110.25
CCV	CAPE CHARLES VORTAC	43.2	212.1°	112.20
ATR	WATERLOO VOR/DME	52.2	25°	112.60
LFI	LANGLEY (HAMPTON) TACAN	65.5	220.1°	112.30

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only