

18VA - Hurt - English

Airport details

State	Virginia
Country	United States of America
Region	
Elevation	547ft (167m)
Timezone	GMT -5
Coordinates	37.10375, -79.30113
Type	helipad
ICAO code	18VA
IATA code	n/a
FAA code	18VA

Communication

No airport communication available for 18VA

Nearby beacons

code	identifier	dist	bearing	frequency
LYH	LYNCHBURG VOR/DME	9.5	23.2°	109.20
LY	BOJAR (LYNCHBURG) NDB	9.9	20°	385
VIT	VINTON (ROANOKE) NDB	28.4	279.8°	277
SBV	SOUTH BOSTON VORTAC	29.1	146.2°	110.40
DAN	DANVILLE VOR	32.1	183.7°	113.10
ODR	WOODRUM (ROANOKE) VOR	35	288°	114.90
ROA	ROANOKE VOR/DME	39.5	287.3°	109.40
UV	BALES (MARTINSVILLE) NDB	42.7	230.1°	396
MOL	MONTEBELLO VOR/DME	48.7	13.7°	115.30
SIF	SLAMMER (REIDSVILLE) NDB	48.7	212.5°	423
HUR	PERSON (ROXBORO) NDB	53.4	164.8°	220
HXO	HUNTSBORO (OXFORD) NDB	58.3	139.6°	271

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only