

ENFL - Florø

Airport details

State	Sogn og Fjordane
Country	Norway
Region	EN
Elevation	37ft (11m)
Timezone	GMT +1
Coordinates	61.58361, 5.02472
Type	land
ICAO code	ENFL
IATA code	FRO
FAA code	n/a

Runway info

Runway 07 / 25	
length	1259m (4131ft)
bearing	81° / 261°
width	30m (98ft)
surface	asphalt
displacement threshold	35m (115ft) / 29m (95ft)

Communication

Florø ATIS	124.625
Florø ATIS	124.625
Florø ATIS	124.625
Florø ATIS	124.625
Florø AFIS	119.200
Florø AFIS	119.200
Florø AFIS	119.200
Florø AFIS	119.200

Approach frequencies

LOC 07 108.9 18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
FLO	FLORO VOR/DME	0.1	245.7°	112.30
BL	BRINGELAND NDB	24	104.7°	374
HN	HOVDEN NDB	44.8	59.8°	389
BVK	BAATVIK NDB	45.2	50°	362

Departure and arrival routes

Transition altitude

6000ft

SID end points

distance

outbound direction

RW07

DOPU1G

82.1

105°

NIDG1G, NIDG1W

31.9

202°

RW25

DOPU1H

82.1

105°

NIDG1H

31.9

202°

STAR starting points

distance

inbound direction

RW07

EMLE1Q

80.9

278°

OLDA1Q

31.1

344°

RW25

EMLE2R

80.9

278°

OLDA2R

31.1

344°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only