

I00 - Chatham - Jefferson-watson

Airport details

State	Virginia
Country	United States of America
Region	
Elevation	799ft (244m)
Timezone	GMT -5
Coordinates	36.83630, -79.40954
Type	land
ICAO code	I00
IATA code	n/a
FAA code	n/a

Runway info

Runway 07 / 25	
length	790m (2592ft)
bearing	68° / 248°
width	37m (120ft)
surface	grass

Communication

No airport communication available for I00

Nearby beacons

code	identifier	dist	bearing	frequency
DAN	DANVILLE VOR	16.4	164.7°	113.10
SBV	SOUTH BOSTON VORTAC	21.3	112.2°	110.40
LYH	LYNCHBURG VOR/DME	26.4	22.4°	109.20
LY	BOJAR (LYNCHBURG) NDB	26.8	21.3°	385
UV	BALES (MARTINSVILLE) NDB	28.5	244.1°	396
VIT	VINTON (ROANOKE) NDB	31.6	307.9°	277
SIF	SLAMMER (REIDSVILLE) NDB	32.1	217.8°	423
HUR	PERSON (ROXBORO) NDB	39.8	150.3°	220
ODR	WOODRUM (ROANOKE) VOR	40	310.5°	114.90
ROA	ROANOKE VOR/DME	43.9	307.5°	109.40
HXO	HUNTSBORO (OXFORD) NDB	49.8	124°	271
HB	ALAMM NDB	52.2	191.5°	361
TEC	TECH (BLACKSBURG) NDB	52.6	290.5°	368
GSO	GREENSBORO VORTAC	54.8	215.6°	116.20
IN	REENO (WINSTON SALEM) NDB	58.7	224.6°	317
LE	LEEVY (RALEIGH/DURHAM) NDB	63.9	142.9°	350

RDU

RALEIGH-DURHAM VORTAC

65.3

146.9°

117.20

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only