

I62 - Brookville - Brookville Air-park

Airport details

State	Ohio
Country	United States of America
Region	
Elevation	1037ft (316m)
Timezone	GMT -5
Coordinates	39.85975, -84.43958
Type	land
ICAO code	I62
IATA code	n/a
FAA code	I62

Runway info

Runway 9 / 27	
length	745m (2444ft)
bearing	89° / 269°
width	9m (30ft)
surface	asphalt

Communication

No airport communication available for I62

Nearby beacons

code	identifier	dist	bearing	frequency
AT	BRUNY (DAYTON) NDB	4.8	96.9°	315
DQN	DAYTON VOR/DME	9.6	15.2°	114.50
MW	ONIDA (MIDDLETOWN) NDB	17.7	157.6°	223
FFO	PATTERSON (DAYTON) TACAN	17.8	96°	115.20
RID	RICHMOND VOR/DME	19.4	255.3°	110.60
HKF	HOOK FIELD (MIDDLETOWN) NDB	21.6	181.2°	239
SGH	DME	27.4	92.2°	113.20
XSF	SPRINGFIELD TACAN	27.6	92°	133.80
AWW	WINCHESTER NDB	28.8	302.5°	212
ROD	ROSEWOOD VORTAC	31.5	42.8°	117.50
SQ	PNTHR (CONNERSVILLE) NDB	32.2	263.1°	227
IL	AIRBO (WILMINGTON) NDB	39.1	117.6°	407
MXQ	MIDWEST (WILMINGTON) VOR/DME	39.2	123.9°	112.90
HW	CUBLA (WILMINGTON) NDB	40	131.9°	299
UWL	NEW CASTLE NDB	40.5	271.3°	385
JN	BALLL (MUNCIE) NDB	44.8	290°	365

MI	BALLL (MUNCIE) NDB	44.8	290°	365
PWF	SPORTYS (BATAVIA) NDB	48.1	164°	245
HLB	BATESVILLE NDB	48.8	237.9°	254
MIE	MUNCIE VOR/DME	49.3	291.5°	114.40
CVG	CINCINNATI VORTAC	52.1	197.3°	117.30

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only