

IS34 - Lawrenceville - Pipers Landing

Airport details

State	Illinois
Country	United States of America
Region	
Elevation	423ft (129m)
Timezone	GMT -6
Coordinates	38.71012, -87.63294
Type	land
ICAO code	IS34
IATA code	n/a
FAA code	IS34

Runway info

Runway 18 / 36	
length	762m (2500ft)
bearing	180° / 360°
width	21m (70ft)
surface	grass

Communication

No airport communication available for IS34

Nearby beacons

code	identifier	dist	bearing	frequency
LWV	DME	3.8	25.9°	108.80
PLX	PALESTINE (ROBINSON) NDB	18.2	358.3°	391
SAM	SAMSVILLE VOR/DME	25.1	243.5°	116.60
OLY	OLNEY NDB	25.2	270.8°	272
EVV	VICCI (EVANSVILLE) NDB	36.1	161.7°	219
FWC	WAYNE CO (FAIRFIELD) NDB	41.5	246.9°	257
BIB	BIBLE GROVE VORTAC	41.6	283.9°	109
HU	YINNO (TERRE HAUTE) NDB	42.1	19.1°	245
PXV	POCKET CITY (EVANSVILLE) VORTAC	47.3	189.4°	113.30
TTH	TERRE HAUTE VORTAC	50	26.2°	115.30
MTO	DME	55.2	319.6°	109.40
OWB	OWENSBORO VOR/DME	62	154.2°	108.60

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only