

KALB - Albany - Albany Intl

Airport details

State	New York
Country	United States of America
Region	K6
Elevation	285ft (87m)
Timezone	GMT -5
Coordinates	42.74396, -73.80087
Type	land
ICAO code	KALB
IATA code	ALB
FAA code	ALB

Runway info

Runway 1 / 19	
length	2593m (8507ft)
bearing	358° / 178°
width	46m (150ft)
surface	asphalt
blast zone	61m (200ft) / 61m (200ft)
Runway 10 / 28	
length	2197m (7208ft)
bearing	89° / 269°
width	46m (150ft)
surface	asphalt
displacement threshold	0m (0ft) / 363m (1191ft)
blast zone	61m (200ft) / 61m (200ft)

Communication

Albany Intl ATIS	120.450
Albany Intl ATIS	120.450
Albany Intl ATIS	120.450
Albany Intl ATIS	120.450
Albany Intl CLNC DEL	127.500
Albany Intl CLNC DEL	127.500
Albany Intl CLNC DEL	127.500
Albany Intl CLNC DEL	127.500
Albany Intl GND	121.700
Albany Intl GND	121.700
Albany Intl GND	121.700
Albany Intl GND	121.700
Albany Intl TWR	119.500
Albany Intl TWR	119.500

Albany Intl TWR	119.500
Albany Intl TWR	119.500
Albany Intl APP	118.050
Albany Intl DEP	118.050
Albany Intl APP	118.050
Albany Intl APP	118.050
Albany Intl DEP	118.050
Albany Intl APP	118.050
Albany Intl DEP	118.050
Albany Intl DEP	118.050

Approach frequencies

ILS-cat-II	01	109.5	18.00mi
ILS-cat-I	19	109.5	18.00mi
3° GS	19	109.5	18.00mi
3° GS	01	109.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
ALB	ALBANY VORTAC	0.2	325.1°	115.30
AL	HAWKY (ALBANY) NDB	4.4	354°	219
HEU	HUNTER (SCHENECTADY) NDB	8.8	309.7°	356
CAM	CAMBRIDGE VOR/DME	25.1	61.2°	115
JJH	JOHNSTOWN NDB	27.9	295.7°	523
PFH	PHILMONT (HUDSON) NDB	29.6	171°	272
GF	GANSE (GLENS FALLS) NDB	31.8	20.8°	209
CTR	CHESTER VOR/DME	46.4	117.9°	115.10
PWL	PAWLING (POUGHKEEPSIE) VOR/DME	59.1	168.3°	114.30
RUT	DME	59.9	47.3°	111
DYO	SMUTO (RUTLAND) NDB	68.5	41.2°	221

Departure and arrival routes

Transition altitude	18000ft
Transition level	18000ft

SID end points	distance	outbound direction
RW01		
	ALB7	12.7 346°
RW10		
	ALB7	12.7 346°
RW19		
	ALB7	12.7 346°
RW28		
	ALB7	12.7 346°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only