KLVL - Lawrenceville - Lawrenceville Brunswick Muni

Airport details

State	Virginia
Country	United States of America
Region	K6
Elevation	328ft (100m)
Timezone	GMT -5
Coordinates	36.77283, -77.79425
Type	land
ICAO code	KLVL
IATA code	LVL
FAA code	LVL

Runway info

Runway 18 / 36	
length	922m (3025ft)
bearing	171° / 351°
width	15m (50ft)
surface	asphalt
Runway 06 / 24	
length	581m (1906ft)
bearing	62° / 242°
width	21m (70ft)
surface	grass

Communication

Lawrenceville Brunswick Muni CTAF/UNICOM	122.800
Lawrenceville Brunswick Muni CTAF/UNICOM	122.800
Lawrenceville Brunswick Muni CTAF/UNICOM	122.800
Lawrenceville Brunswick Muni CTAF/UNICOM	122.800

Nearby beacons

code	identifier	dist	bearing	frequency
LVL	LAWRENCEVILLE VORTAC	5.8	292.5°	112.90
BKT	BLACKSTONE NDB	24.4	324.7°	326
FKN	FRANKLIN VORTAC	37.7	94.2°	110.60

AKQ	WAKEFIELD NDB	40.1	75.1°	274
FAK	FLAT ROCK VORTAC	45.4	357.4°	113.30
HPW	HOPEWELL VORTAC	46.6	50.6°	112
TYI	TAR RIVER (ROCKY MOUNT) VORTAC	48	173.5°	117.80
HXO	HUNTSBORO (OXFORD) NDB	48.8	240.2°	271
RIC	RICHMOND VORTAC	49.3	33°	114.10
CVI	COFIELD VORTAC	50.5	113.4°	114.60
LE	LEEVY (RALEIGH/DURHAM) NDB	67.7	227.6°	350
RDU	RALEIGH-DURHAM VORTAC	72.2	227.6°	117.20

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only