

KVAD - Valdosta - Moody Afb

Airport details

State	Georgia
Country	United States of America
Region	K7
Elevation	231ft (70m)
Timezone	GMT -5
Coordinates	30.96870, -83.19296
Type	land
ICAO code	KVAD
IATA code	VAD
FAA code	VAD

Runway info

Runway 18L / 36R	
length	2837m (9308ft)
bearing	181° / 1°
width	46m (150ft)
surface	concrete
blast zone	255m (837ft) / 255m (837ft)
Runway 18R / 36L	
length	2441m (8009ft)
bearing	181° / 1°
width	46m (150ft)
surface	asphalt
blast zone	255m (837ft) / 255m (837ft)

Communication

Moody AFB GND	120.625
Moody AFB GND	120.625
Moody AFB GND	120.625
Moody AFB GND	120.625
Moody AFB TWR	128.450
Moody AFB TWR	128.450
Moody AFB TWR	128.450
Moody AFB TWR	128.450
Moody AFB VALDOSTA APP	119.525
Moody AFB VALDOSTA APP	126.600
Moody AFB VALDOSTA APP	127.925
Moody AFB VALDOSTA APP	127.925
Moody AFB VALDOSTA APP	126.600
Moody AFB VALDOSTA APP	127.925
Moody AFB VALDOSTA APP	119.525

Moody AFB VALDOSTA APP	119.525
Moody AFB VALDOSTA APP	127.925
Moody AFB VALDOSTA APP	126.600
Moody AFB VALDOSTA APP	119.525
Moody AFB VALDOSTA APP	126.600
Moody AFB VALDOSTA DEP	126.600
Moody AFB VALDOSTA DEP	126.600
Moody AFB VALDOSTA DEP	126.600
Moody AFB VALDOSTA DEP	126.600

Approach frequencies

ILS-cat-I	36R	109.9	18.00mi
ILS-cat-I	18L	109.3	18.00mi
3° GS	36R	109.9	18.00mi
3° GS	18L	109.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
VAD	MOODY (VALDOSTA) TACAN	0.5	183.2°	113.30
OTK	VALDOSTA VOR/DME	12.1	204.7°	114.80
HOE	HOMERVILLE NDB	22.2	78.3°	209
OWC	COFFEE COUNTY (DOUGLAS) NDB	29.6	31.6°	390
IFM	TIFT MYERS (TIFTON) VOR	31.5	327.2°	112.50
MGR	DME	32.1	280.5°	108.80
GTP	PATON (THOMASVILLE) NDB	32.6	268.9°	245
AYS	WAYCROSS VORTAC	37.3	64.7°	110.20
SUR	FITZGERALD NDB	39	351.3°	362
GEF	GREENVILLE VORTAC	39.4	234.7°	109
TAY	TAYLOR VORTAC	43.2	125.9°	112.90
AY	WIKET (WAYCROSS) NDB	46.1	65.8°	219
AMG	ALMA VORTAC	48.9	50.3°	115.10
CYR	CAIDY (CAIRO) NDB	50	265.2°	338
LCQ	LAKE CITY NDB	56.7	141.8°	204
BHC	BAXLEY NDB	60.7	47.2°	376
AZE	HAZLEHURST NDB	61.4	30.9°	414

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only