

LTAP - Amasya - Merzifon

Airport details

State	Amasya Province
Country	Turkey
Region	LT
Elevation	1755ft (535m)
Timezone	GMT +3
Coordinates	40.82944, 35.52222
Type	land
ICAO code	LTAP
IATA code	MZH
FAA code	n/a

Runway info

Runway 05R / 23L	
length	2923m (9590ft)
bearing	62° / 242°
width	45m (148ft)
surface	asphalt
blast zone	255m (837ft) / 150m (492ft)
Runway 05L / 23R	
length	2738m (8983ft)
bearing	62° / 242°
width	23m (75ft)
surface	asphalt
blast zone	150m (492ft) / 150m (492ft)

Communication

Merzifon ATIS	122.425
Merzifon ATIS	122.425
Merzifon ATIS	122.425
Merzifon ATIS	122.425
Merzifon GND	121.950
Merzifon GND	121.950
Merzifon GND	121.950
Merzifon GND	121.950
Merzifon TWR	122.100
Merzifon TWR	122.100
Merzifon TWR	122.100
Merzifon TWR	122.100
Merzifon APP	122.100
Merzifon APP	122.100
Merzifon APP	122.100

Approach frequencies

ILS-cat-I	05R	110.5	18.00mi
3° GS	05R	110.5	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
MNI	MERZIFON NDB	0.6	229.4°	440
TKT	TOKAT NDB	49.7	121°	403

Departure and arrival routes

Transition altitude 10000ft

SID end points **distance** **outbound direction**

RW05L

HAVZ1N, HAVZ1M	24.2	57°
ERGU1N, ERGU1M	35.9	264°

RW05R

HAVZ1D, HAVZ1C	24.2	57°
ERGU1D, ERGU1C	35.9	264°

RW23L

HAVZ1K, HAVZ1E	24.2	57°
ERGU1K, ERGU1E	35.9	264°

RW23R

HAVZ1P, HAVZ1S	24.2	57°
ERGU1P, ERGU1S	35.9	264°

STAR starting points

distance

inbound direction

ALL

ERGU1A, ERGU1B	35.9	84°
HAVZ1A, HAVZ1B	24.2	237°

RW05R

ERGU1F	35.9	84°
--------	------	-----

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
AKED1A	MNI	NDB	right	49 (229)°	> 9000ft	1.0min timed	230
AKED1B	MNI	NDB	right	49 (229)°	> 9000ft	1.0min timed	230
ERGU1A	MNI	NDB	right	49 (229)°	> 9000ft	1.0min timed	230
ERGU1B	MNI	NDB	right	49 (229)°	> 9000ft	1.0min timed	230
ERGU1F	AP612	VHF	right	229 (49)°	> 7500ft	1.0min timed	ICAO rules
HAVZ1A	MNI	NDB	right	49 (229)°	> 9000ft	1.0min timed	230

HAVZ1B MNI NDB right 49 (229)° > 9000ft 1.0min timed 230

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only