

RJTY - Fussa - Yokota Ab

Airport details

State	Tōkyō Prefecture
Country	Japan
Region	RJ
Elevation	460ft (140m)
Timezone	GMT +9
Coordinates	35.74849, 139.34848
Type	land
ICAO code	RJTY
IATA code	OKO
FAA code	n/a

Runway info

Runway 18 / 36	
length	3362m (11030ft)
bearing	168° / 348°
width	61m (200ft)
surface	concrete
blast zone	255m (837ft) / 255m (837ft)

Communication

YOKOTA AB ATIS	128.400
YOKOTA AB ATIS	128.400
YOKOTA AB ATIS	128.400
YOKOTA AB ATIS	128.400
YOKOTA AB CLNC DEL	131.400
YOKOTA AB CLNC DEL	131.400
YOKOTA AB CLNC DEL	131.400
YOKOTA AB CLNC DEL	131.400
YOKOTA AB GND	133.200
YOKOTA AB GND	133.200
YOKOTA AB GND	133.200
YOKOTA AB GND	133.200
YOKOTA AB TWR	134.300
YOKOTA AB TWR	134.300
YOKOTA AB TWR	134.300
YOKOTA AB TWR	134.300
YOKOTA AB APP	118.300
YOKOTA AB APP	123.800
YOKOTA AB APP	123.800
YOKOTA AB APP	118.300
YOKOTA AB APP	118.300

YOKOTA AB APP	123.800
YOKOTA AB APP	118.300
YOKOTA AB APP	123.800
YOKOTA AB DEP	122.100
YOKOTA AB DEP	122.100
YOKOTA AB DEP	122.100
YOKOTA AB DEP	122.100

Approach frequencies

ILS-cat-I	18	108.7	18.00mi
ILS-cat-I	36	109.7	18.00mi
3° GS	18	108.7	18.00mi
2.5° GS	36	109.7	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
YOK	YOKOTA (TOKYO) TACAN	0	74.9°	113.80
TN	SHIN-TACHIKAWA NDB	3	120.4°	366
TNT	TACHIKAWA TACAN	3.1	122°	115.80
YLT	IRUMA TACAN	6.3	36.1°	110.60
NJA	ATSUGI TACAN	18.9	160.8°	115.10
HME	HANEDA (TOKYO) VOR/DME	23	114.2°	112.20
SYE	SEKIYADO VOR/DME	28.6	61.8°	117
HYD	DME	31.8	154.1°	116.20
SHT	SHIMOFUSA (MATSUDO) TACAN	32.3	85.3°	108.20
SND	(TOKYO) DME	32.7	73.5°	114
KZT	KISARAZU TACAN	34.3	122.2°	110.05
TLD	DME	44.8	72.3°	116
JD	NIKKO (UTSUNOMIYA) NDB	50.9	34.8°	389
TET	TATEYAMA TACAN	52.5	147.8°	108.80
JDT	UTSUNOMIYA TACAN	52.7	34.4°	112.15
PQD	DME	55.1	145.7°	112.50
OSE	MIHARA (OSHIMA) VOR/DME	57.7	179°	109.85

Departure and arrival routes

Transition altitude	14000ft
Transition level	14000ft

SID end points	distance	outbound direction
RW18		
BREEE4, GERGE2	18.0	169°
BUSYU1	26.9	275°
RW36		
BUSYU1	26.9	275°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only