

SAAR - Rosario - Rosario (islas Malvinas)

Airport details

State	Santa Fe
Country	Argentina
Region	SA
Elevation	83ft (25m)
Timezone	GMT -3
Coordinates	-32.90361, -60.78444
Type	land
ICAO code	SAAR
IATA code	ROS
FAA code	n/a

Runway info

Runway 02 / 20	
length	3003m (9852ft)
bearing	13° / 193°
width	45m (148ft)
surface	concrete

Communication

Rosario (Islas Malvinas) TWR	118.700
Rosario (Islas Malvinas) TWR	118.700
Rosario (Islas Malvinas) TWR	118.700
Rosario (Islas Malvinas) TWR	118.700
Rosario (Islas Malvinas) APP	118.700
Rosario (Islas Malvinas) APP	118.700
Rosario (Islas Malvinas) APP	118.700
Rosario (Islas Malvinas) APP	118.700

Approach frequencies

ILS-cat-I	20	109.9	18.00mi
3° GS	20	109.9	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
ROS	ROSARIO VOR/DME	0.1	114.9°	117.30
F	ISLAS MALVINAS (ROSARIO) NDB	1.2	12.3°	305

Departure and arrival routes

Transition altitude

3000ft

SID end points

distance

outbound direction

RW02

DABO1C	29.9	15°
TINT1C	30.2	93°
VASA1C	30.1	145°
VUMK1C	19.1	221°
GEDU1C	29.8	279°
TOLU2C	29.8	296°
VUKS1C	30.0	339°
MUPI1C	29.9	359°

RW20

DABO1G	29.9	15°
TINT1G	30.2	93°
VASA1G	30.1	145°
VUMK1G	19.1	221°
GEDU1G	29.8	279°
TOLU2G	29.8	296°
VUKS1G	30.0	339°
MUPI1G	29.9	359°

STAR starting points

distance

inbound direction

RW02

VUMK1Q	19.1	41°
GEDU1Q	29.8	99°
ROKE1Q	72.6	143°
VUKS1Q	30.0	159°
MUPI1Q	29.9	179°
DABO1Q	29.9	195°
TINT1Q	30.2	273°
ESKO1Q	30.2	306°

RW20

VUMK1U	19.1	41°
GEDU1U	29.8	99°
ROKE1U	72.6	143°
VUKS1U	30.0	159°
MUPI1U	29.9	179°
DABO1U	29.9	195°
TINT1U	30.2	273°
ESKO1U	30.2	306°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only