

SAZM - Mar Del Plata - Astor Piazzolla

Airport details

State	Buenos Aires
Country	Argentina
Region	SA
Elevation	69ft (21m)
Timezone	GMT -3
Coordinates	-37.93417, -57.57333
Type	land
ICAO code	SAZM
IATA code	MDQ
FAA code	n/a

Runway info

Runway 13 / 31	
length	2198m (7211ft)
bearing	117° / 297°
width	45m (148ft)
surface	asphalt
blast zone	51m (167ft) / 0m (0ft)

Communication

Astor Piazzolla GND	121.700
Astor Piazzolla GND	121.700
Astor Piazzolla GND	121.700
Astor Piazzolla GND	121.700
Astor Piazzolla TWR	118.750
Astor Piazzolla TWR	118.750
Astor Piazzolla TWR	118.750
Astor Piazzolla TWR	118.750
Astor Piazzolla APP	118.750
Astor Piazzolla APP	118.750
Astor Piazzolla APP	118.750
Astor Piazzolla APP	118.750
Astor Piazzolla DEP	118.750
Astor Piazzolla DEP	118.750
Astor Piazzolla DEP	118.750
Astor Piazzolla DEP	118.750

Approach frequencies

ILS-cat-I	13	109.5	18.00mi
-----------	----	-------	---------

3° GS 13 109.5 18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
MDP	MAR DEL PLATA VOR/DME	0.2	324.3°	116.20
GES	VILLA GESSELL NDB	49.4	38.1°	242

Departure and arrival routes

Transition altitude 3000ft

SID end points **distance** **outbound direction**

RW13

ROPI1D, ROPI1C	77.4	27°
ROGA1C	29.9	240°
SIRA1C	30.1	260°
ESUR1C	30.2	293°
PULP1D, PULP1C	56.6	353°

RW31

ROPI1G	77.4	27°
ROGA1G	29.9	240°
SIRA1G	30.1	260°
ESUR1G	30.2	293°
PULP1G	56.6	353°

STAR starting points **distance** **inbound direction**

RW13

ROGA1Q	29.9	60°
SIRA1Q	30.1	80°
ESUR1Q	30.2	113°
VOTR1Q	56.6	152°
MUDN1Q	72.7	197°
ROPI1Q, ROPI1R	77.4	207°

RW31

ROGA1U	29.9	60°
SIRA1U	30.1	80°
ESUR1U	30.2	113°
VOTR1U	56.6	152°
MUDN1U	72.7	197°
ROPI1U	77.4	207°

Holding patterns

STAR name	hold at	type	turn	heading*	altitude	leg	speed limit
ESUR1Q	ESURO	VHF	right	300 (120)°		DME 4.0mi	210
ESUR1U	ESURO	VHF	right	300 (120)°		DME 4.0mi	210

SIRA1Q	SIRAN	VHF	right	248 (68)°	DME 4.0mi	210
SIRA1U	SIRAN	VHF	right	248 (68)°	DME 4.0mi	210
VOTR1Q	VOTRA	VHF	right	358 (178)°	DME 7.0mi	240
VOTR1U	VOTRA	VHF	right	358 (178)°	DME 7.0mi	240

*) magnetic outbound (inbound) holding course

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only