

SBJP - João Pessoa - Presidente Castro Pinto

Airport details

State	Paraíba
Country	Brazil
Region	SB
Elevation	213ft (65m)
Timezone	GMT -3
Coordinates	-7.14833, -34.95028
Type	land
ICAO code	SBJP
IATA code	JPA
FAA code	n/a

Runway info

Runway 16 / 34	
length	2526m (8287ft)
bearing	135° / 315°
width	45m (148ft)
surface	asphalt
blast zone	59m (194ft) / 60m (197ft)

Communication

Presidente Castro Pinto PESSOA TWR 118.300
Presidente Castro Pinto PESSOA TWR 118.300
Presidente Castro Pinto PESSOA TWR 118.300
Presidente Castro Pinto PESSOA TWR 118.300
Presidente Castro Pinto PESSOA CON 118.300
Presidente Castro Pinto PESSOA CON 118.300
Presidente Castro Pinto PESSOA CON 118.300
Presidente Castro Pinto PESSOA CON 118.300

Nearby beacons

code	identifier	dist	bearing	frequency
JPS	PESSOA DME	0.1	52.6°	114
JPS	JOAO PESSOA NDB	0.4	344.1°	320
YGA	DME	41.9	175.3°	112.90
CPG	CAMPINA GRANDE NDB	56.5	262.8°	230
IF	IBURA (RECIFE) NDB	57.9	178.8°	220
REC	RECIFE VOR/DME	59.3	178.6°	116.90
VSA	DE SANTO ANTAO DME	60.9	199.3°	113.70

Departure and arrival routes

Transition altitude	5000ft
Transition level	50ft

SID end points	distance	outbound direction
RW16		
ANDAD, UGIBO, REC	59.3	179°
GELE1A	49.0	272°
PAKIL	53.4	277°
NTL1, SAFUC1, TOREM	76.5	346°
RW34		
REC, UGIBO, ANDAD	59.3	179°
PAKIL	53.4	277°
SAFUC1, TOREM, NTL1	76.5	346°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only