

SEQM - Quito - Quito - Mariscal Sucre

Airport details

State	Pichincha
Country	Ecuador
Region	SE
Elevation	7838ft (2389m)
Timezone	GMT -5
Coordinates	-0.12417, -78.35445
Type	land
ICAO code	SEQM
IATA code	UIO
FAA code	n/a

Runway info

Runway 18 / 36	
length	4118m (13510ft)
bearing	178° / 358°
width	45m (148ft)
surface	asphalt

Communication

Quito - Mariscal Sucre ATIS 1	115.300
Quito - Mariscal Sucre QUITO ATIS	118.900
Quito - Mariscal Sucre ATIS 2	114.800
Quito - Mariscal Sucre ATIS 2	114.800
Quito - Mariscal Sucre ATIS 1	115.300
Quito - Mariscal Sucre QUITO ATIS	118.900
Quito - Mariscal Sucre QUITO ATIS	118.900
Quito - Mariscal Sucre ATIS 1	115.300
Quito - Mariscal Sucre ATIS 2	114.800
Quito - Mariscal Sucre ATIS 2	114.800
Quito - Mariscal Sucre ATIS 1	115.300
Quito - Mariscal Sucre QUITO ATIS	118.900
Quito - Mariscal Sucre Quito	128.800
Clearance Delivery	
Quito - Mariscal Sucre Quito	128.800
Clearance Delivery	
Quito - Mariscal Sucre Quito	128.800
Clearance Delivery	
Quito - Mariscal Sucre Quito	128.800
Clearance Delivery	
Quito - Mariscal Sucre QUITO Ground	121.900
Quito - Mariscal Sucre QUITO Ground	121.900

Quito - Mariscal Sucre QUITO Ground	121.900
Quito - Mariscal Sucre QUITO Ground	121.900
Quito - Mariscal Sucre Departure 1	119.700
Quito - Mariscal Sucre QUITO Tower	118.100
Quito - Mariscal Sucre Departure 1	119.700
Quito - Mariscal Sucre QUITO Tower	118.100
Quito - Mariscal Sucre QUITO Tower	118.100
Quito - Mariscal Sucre Departure 1	119.700
Quito - Mariscal Sucre QUITO Tower	118.100
Quito - Mariscal Sucre Departure 1	119.700
Quito - Mariscal Sucre QUITO	121.200
Approach 2	
Quito - Mariscal Sucre QUITO	119.700
Approach	
Quito - Mariscal Sucre QUITO	121.200
Approach 2	
Quito - Mariscal Sucre QUITO	119.700
Approach	
Quito - Mariscal Sucre QUITO	119.700
Approach	
Quito - Mariscal Sucre QUITO	121.200
Approach 2	
Quito - Mariscal Sucre QUITO	119.700
Approach	
Quito - Mariscal Sucre QUITO	121.200
Approach 2	
Quito - Mariscal Sucre Departure 2	121.200
Quito - Mariscal Sucre Departure 2	121.200
Quito - Mariscal Sucre Departure 2	121.200
Quito - Mariscal Sucre Departure 2	121.200

Approach frequencies

ILS-cat-II	36	109.3	18.00mi
ILS-cat-I	18	111.1	18.00mi
3.2° GS	18	111.1	18.00mi
3.2° GS	36	109.3	18.00mi

Nearby beacons

code	identifier	dist	bearing	frequency
QNV	NORTE VOR/DME	8.4	357.5°	117.40
QSV	SUR (QUITO) VOR/DME	10.6	176.5°	116.80
QIT	CONDORCOCHA (QUITO) VOR/DME	10.7	298.6°	115.30
OLM	OLMEDO NDB	23.8	41.2°	400
LTV	LATACUNGA VOR/DME	50.6	198.1°	117.10
STD	SANTO DOMINGO NDB	51.7	261.7°	270
TLC	TULCAN NDB	69.6	35.1°	418
SLI	SAN LUIS (IPIALES) NDB	71.6	34.7°	244

IPI	IPIALES VOR/DME	71.9	34.6°	113.60
JUV	JUMANDY VOR/DME	73.5	139.8°	114.30

Departure and arrival routes

Transition altitude 18000ft

SID end points	distance	outbound direction
RW18		
QIT3A	10.7	299°
RW36		
ARNO2A, ARNOK3	40.1	21°
ANBAL2	40.6	28°
SIMOG3, SIMO1B	45.7	69°
VURIS2	60.6	169°
KETO2A, KETO2B	60.5	186°
REBE2B, REBE2A	59.8	198°
TEMO1C, TEMO2A, TEMO2B	54.0	239°
ORET1C, ORET2B, ORET2A	50.7	257°
MIDE3A, MIDE2C, MIDE3B	47.4	275°
QIT2	10.7	299°
PALAD3, PALA4A	42.2	309°
NEGAL1, NEGA2A	39.7	340°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only