

SVBL - El Libertador Ab

Airport details

State	Aragua State
Country	Venezuela
Region	SV
Elevation	1450ft (442m)
Timezone	GMT -4
Coordinates	10.18306, -67.55695
Type	land
ICAO code	SVBL
IATA code	n/a
FAA code	n/a

Runway info

Runway 09 / 27	
length	3413m (11198ft)
bearing	82° / 262°
width	48m (157ft)
surface	concrete
blast zone	255m (837ft) / 255m (837ft)

Communication

EL LIBERTADOR AB ATIS	132.750
EL LIBERTADOR AB ATIS	132.750
EL LIBERTADOR AB ATIS	132.750
EL LIBERTADOR AB ATIS	132.750
EL LIBERTADOR AB LIBERTADOR OPS	119.300
EL LIBERTADOR AB LIBERTADOR OPS	119.300
EL LIBERTADOR AB LIBERTADOR OPS	119.300
EL LIBERTADOR AB LIBERTADOR OPS	119.300
EL LIBERTADOR AB TWR	122.300
EL LIBERTADOR AB Tower	122.500
EL LIBERTADOR AB TWR	124.300
EL LIBERTADOR AB TWR	122.300
EL LIBERTADOR AB TWR	124.300
EL LIBERTADOR AB Tower	122.500
EL LIBERTADOR AB TWR	122.300
EL LIBERTADOR AB Tower	122.500
EL LIBERTADOR AB TWR	124.300
EL LIBERTADOR AB TWR	122.300
EL LIBERTADOR AB Tower	122.500
EL LIBERTADOR AB TWR	124.300
EL LIBERTADOR AB APP	120.800

EL LIBERTADOR AB APP	120.800
EL LIBERTADOR AB APP	120.800
EL LIBERTADOR AB APP	120.800

Nearby beacons

code	identifier	dist	bearing	frequency
BAL	EL LIBERTADOR (MARACAY) VOR/DME	0.4	88.6°	113.90
BEL	BELEN NDB	14.2	216.7°	235
VAL	VALENCIA VOR/DME	21.7	264.5°	117.40
SSB	SAN SEBASTIAN NDB	27.5	118.8°	318
PBL	PUERTO CABELLO VOR/DME	35.6	300°	117.70
MIQ	MAIQUETIA VOR/DME	42.1	53°	114.80
TUY	TUY (CARACAS) VOR/DME	45.2	81.8°	115.20

Departure and arrival routes

Transition altitude 10000ft

SID end points	distance	outbound direction
RW09		
ORODI1	28.1	57°
MASPU1	27.5	119°
VAL1	21.7	265°
RW27		
ORODI1	28.1	57°
MASPU1	27.5	119°
VAL1	21.7	265°

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only