

TTL - Blue Lagoon Seaplane Base - Turtle Island

Airport details

State	Western
Country	Fiji
Region	
Elevation	0ft (0m)
Timezone	GMT +12
Coordinates	-16.93450, 177.36443
Type	sea base
ICAO code	TTL
IATA code	n/a
FAA code	n/a

Runway info

Runway 01 / 19	
length	442m (1450ft)
bearing	191° / 11°
width	40m (131ft)

Communication

No airport communication available for TTL

Nearby beacons

code	identifier	dist	bearing	frequency
NN	NADI VOR/DME	43.2	177.5°	112.50
VK	NAVAKAI (NADI) NDB	51.1	176.2°	405
MI	MOMI (NADI) NDB	58	182.3°	364

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only