

# YADD - Cocklebidy - Arubiddy Station

---

## Airport details

|             |                      |
|-------------|----------------------|
| State       | Western Australia    |
| Country     | Australia            |
| Region      | YM                   |
| Elevation   | 398ft (121m)         |
| Timezone    | GMT +8               |
| Coordinates | -31.80953, 125.91669 |
| Type        | land                 |
| ICAO code   | YADD                 |
| IATA code   | n/a                  |
| FAA code    | n/a                  |

## Runway info

|                |                |
|----------------|----------------|
| Runway 16 / 34 |                |
| length         | 1094m (3589ft) |
| bearing        | 144° / 324°    |
| width          | 30m (98ft)     |
| surface        | dirt           |
| Runway 01 / 19 |                |
| length         | 1059m (3474ft) |
| bearing        | 12° / 192°     |
| width          | 30m (98ft)     |
| surface        | dirt           |
| Runway 07 / 25 |                |
| length         | 1000m (3281ft) |
| bearing        | 72° / 252°     |
| width          | 23m (75ft)     |
| surface        | dirt           |

## Communication

|                       |         |
|-----------------------|---------|
| Arubiddy Station CTAF | 126.700 |
| Arubiddy Station CTAF | 126.700 |
| Arubiddy Station CTAF | 126.700 |
| Arubiddy Station CTAF | 126.700 |

# Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

## To be used with X-Plane simulation only