

YTQY - Torquay

Airport details

State	Victoria
Country	Australia
Region	YM
Elevation	28ft (9m)
Timezone	GMT +11
Coordinates	-38.30000, 144.36501
Type	land
ICAO code	YTQY
IATA code	n/a
FAA code	n/a

Runway info

Runway 13 / 31	
length	628m (2060ft)
bearing	135° / 315°
width	37m (121ft)
surface	grass
Runway 09 / 27	
length	482m (1581ft)
bearing	98° / 278°
width	30m (98ft)
surface	grass
Runway 18 / 36	
length	709m (2326ft)
bearing	193° / 13°
width	59m (194ft)
surface	grass

Communication

Torquay CTAF	119.000
Torquay CTAF	119.000
Torquay CTAF	119.000
Torquay CTAF	119.000

Nearby beacons

code	identifier	dist	bearing	frequency
AV	AVALON VOR/DME	15.7	20.5°	116.10
MB	MOORABBIN (MELBOURNE) NDB	39.3	65.9°	398
ML	MELBOURNE VOR/DME	44.5	36.7°	114.10

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only