

LFPL - Paris - Lognes Emerainville

Airport details

State	Ile-de-France
Country	France
Region	LF
Elevation	354ft (108m)
Timezone	GMT +1
Coordinates	48.82207, 2.62680
Type	land
ICAO code	LFPL
IATA code	n/a
FAA code	n/a

Runway info

Runway 08R / 26L	
length	1101m (3612ft)
bearing	84° / 264°
width	114m (373ft)
surface	grass
Runway 08 / 26	
length	701m (2300ft)
bearing	84° / 264°
width	20m (66ft)
surface	asphalt

Communication

Lognes Emerainville LOGNES Atis	125.025
Lognes Emerainville LOGNES Atis	125.025
Lognes Emerainville LOGNES Atis	125.025
Lognes Emerainville LOGNES Atis	125.025
Lognes Emerainville LOGNES Ground	122.125
Lognes Emerainville LOGNES Ground	122.125
Lognes Emerainville LOGNES Ground	122.125
Lognes Emerainville LOGNES Ground	122.125
Lognes Emerainville LOGNES Tower	118.600
Lognes Emerainville LOGNES Tower	118.600
Lognes Emerainville LOGNES Tower	118.600
Lognes Emerainville LOGNES Tower	118.600

Nearby beacons

code	identifier	dist	bearing	frequency
------	------------	------	---------	-----------

PGS	CHARLES-DE-GAULLE (PARIS) VOR/DME	10.6	359°	117.05
POY	ORLY (PARIS) NDB	10.8	248.8°	334
BT	LE BOURGET (PARIS) VOR/DME	11.3	311.6°	116.10
CGN	(PARIS) DME	12.8	327.3°	115.35
CLM	COULOMMIERS VOR/DME	15.3	86.6°	112.90
TA	VILLACOUBLAY NDB	21.1	264.5°	286
TSU	TOUSSUS LE NOBLE VOR	21.1	262.5°	108.25
MV	MELUN NDB	21.2	127.3°	434
MLN	MELUN VILLAROCHE VOR/DME	23.2	153°	113.60
RBT	RAMBOUILLET VOR/DME	27	255.1°	114.70
BSN	DME	27.7	49.5°	114.85
PON	PONTOISE CORMEILLES EN VE VOR	28.5	294.8°	111.60
HOL	VILLACOUBLAY NDB	32.3	263.5°	315
BRY	BRAY SUR SEINE VOR/DME	36.3	121.8°	114.10
EPR	EPERNON VOR/DME	40.2	258.5°	115.65
BOV	BEAUVAIS TILLE VOR/DME	41.3	322.3°	109.65
CTL	CHATILLON SUR MARNE VOR/DME	42	71.6°	117.60
PTV	PITHIVIERS VOR	42.5	208.5°	116.50
MTD	MONTDIDIER VOR	44.2	349.3°	113.65
BV	BEAUVAIS NDB	46.5	318.2°	391
ORS	ORLEANS SAINT DENIS DE L'HOTEL NDB	55.2	203.4°	322
OAN	ORLEANS-BRICY NDB	60	226.2°	385
BCY	ORLEANS VOR/DME	61	226.1°	117.35
AX	AUXERRE NDB	64.4	135.8°	417

Disclaimer

The information on this website is not for real aviation. Use this data with the X-Plane flight simulator only! Data taken with kind consent from X-Plane source code and data files. Content is subject to change without notice.

To be used with X-Plane simulation only